iPhone Tips July 2023

Mute "Reply-All" Email Threads:

- Open Mail app on iPhone
- In your inbox, swipe right to left across the message you wish to mute
- · Tap More
- Tap Mute
- If you want to rejoin the conversation, repeat the first three steps, but tap Unmute.

Type Faster by Swiping:

 To "type" drag and hold your finger or thumb on each letter of the word you're trying to spell.

Change Your Profile Picture in Messages:

- Open your Messages app
- Tap the ••• button on the top righthand side of screen
- Select "Edit Name and Photo"
- Tap on the profile icon to change your image
- You can snap a photo using the camera, upload a photo from your photo library, or use an Animoji or Memoji instead

Change Wi-Fi Networks Faster

- Open Control Center by swiping down diagonally on the top-right corner of your iPhone's display
- Tap and long hold your finger on the middle of the Wi-Fi widget
- Press and long hold your finger on Wi-Fi bars icon to see a list of available networks
- This trick also works for pairing Bluetooth devices.

<u>Automatically Close Browser Tabs (only works with default Safari internet browser):</u>

- Open the Settings app
- Tap Safari

- Tap Close Tabs
- You can set it to close your tabs each day, each week, every month, or leave it on manual mode.

Take More Level. Better-Framed Photos:

- Go to Settings
- Scroll down to Camera and tap
- Enable the Grid

When you hold your phone over something to take a photo, two crosshairs will appear - a white one and a yellow one. When they line up, your photo is level.

Delete Multiple Emails at Once:

Go to the mail app and choose All Inboxes (or a certain account if you have more than one). Click Edit in the upper right-hand corner and circles appear next to the emails. Simply swipe down on multiple emails you wish to eliminate and a check mark will appear in the circle. Move to trash.

View All of Your App Screens at Once:

Long press one of your Home Screens. It will start the jiggle mode. At the bottom you will see the dots that represent the number of home page screens you have. Long hold those dots. You can hide a screen page or add one here.

Hang Up Via Airplane Mode:

Hanging up on someone is impolite, but sometimes you need to. While on the call, switch to Airplane Mode. The call will be ended as though it was a dropped call.